

Trigger – can be used for PTT or engage - disengage

Two controls – can be used for Electric Flaps up & Down



Side view



Front view

Button – can be used for engage - disengage